



INSTALLATION

> Instructions

Thule Omnistor Motor Kit 12V 301296 - 301298





DE Markise -
Anleitung
NL Luifel -
Instructies
FR Store -
Instructions
IT Tendalino -
Istruzioni
ES Toldo -
Instrucciones
SV Markisen -
Instruktioner
FI Markiisit -
Ohjeet
DA Markisen -
Instruktioner
NO Markisen -
Instruksjoner

PL Markiza -
Instrukcje
PT Toldo -
Instruções
CS Markýza -
Návod
SL Ponjava -
Navodila
TR Güneşlik -
Talimatlar
ZH 遮阳篷 -
说明
JA オーニング -
取扱説明書
KO 어닝 -
지침

1 **WARNINGS & INFO**

4

Warnungen & Infos / Waarschuwingen & info / Avertissements & informations / Avvertenze & informazioni / Advertencias & información / Varningar & information / Varoituksia & tietoja / Advarsler & info / Advarsler & information / Ostrzeżenia & informacje / Avisos e informações / Varování a informace / Opozorila in informacije / Uyarılar ve Bilgiler / 警告和信息 / 警告と情報 / 경고 및 정보

2 **CONTENT**

4

Inhalt / Inhoudsopgave / Sommaire / Contenuto / Contenido / Innehåll / Sisällys / Indhold / Innhold / Treść / Índice / Obsah / Kazalo / İçerik / 目录 / 目次 / 목차

3 **TOOLS**

4

Werkzeuge / Gereedschappen / Outils / Strumenti / Herramientas / Verktøy / Työkalut / Værktøj / Verktøy / Narzędzia / Ferramentas / Nářadí / Orodja / Aletler / 工具 / ツール / 도구

4 **INSTALLATION**

5

Montage / Installatie / Installation / Installazione / Instalación / Montering / Asennus / Montering / Montering / Montaj / Instalação / Montáž / Namestitev / Montaj / 安装 / 取り付け / 설치

5 **ELECTRICAL INSTALLATION**

8

Elektrische Installation / Elektrische installatie / Installation électrique / Installazione elettrica / Instalación eléctrica / Elinstallation / Sähköasennus / Elektrisk montering / Elektrisk montering / Instalacja elektryczna / Instalação eléctrica / Elektroinstalace / Električna namestitev / Elektrik Montaji / 电气装置 / 電動取り付け / 전기적 설치

6 **MANUAL OVERRIDE**

13

Manuelle Freigabe / Handmatige ontkoppeling / Déblocage manuel / Sgancio manuale / Liberación manual / Manuell frigöring / Manuaalinen vapautus / Manuel udløsning / Manuell utløsning / Demontaż ręczny / Desengate manual / Ruční odepnutí / Ročno odpenjanje / El ile kilit açma / 手动卸载 / 手動リリース / 수동 해제

1 WARNINGS & INFO



> Instructions


> Safety



OK



NOT
OK




Instructions


Safety




2 CONTENT



x1



x1




x1



x1



x1




x1

3 TOOLS





TX20



4 INSTALLATION

THULE AWNING LENGTH	MOTOR KIT 12V
1,90 m	✗
2,30 m	✗
2,60 m	✗
3 m	✓
3,50 m	✓
4 m	✓
4,50 m	✓
5 m	✓


1




2



A




B




3



A



B




5 ELECTRICAL INSTALLATION

i



UK
CA




THULE MOTOR 12V
TECHNICAL SPECIFICATIONS


Supply	12V DC
Current	Nominal: 10A / Peak: 20,5A
Nominal Torque	3 Nm
Nominal Speed	58 - 70 rpm
Mechanical Limit Setting	✓
Emergency Manual Operation	✓

THULE CONTROL BOX
TECHNICAL SPECIFICATIONS

Supply	12V DC
Maximum Voltage	18V DC
Standby Power Consumption	< 0,2 mA
Storage Tempature Range	-40°C to +80°C
Operation Tempature Range	-25°C to +80°C
IP classification	IP 51
Noise	65 dB (C)





2




3




X

Max. 10m






X > 10m




4

Y

A




C




5

Z

B




D




6 MANUAL OVERRIDE


1




2




3



4



5



6

